

XMT-450 Firmware Release Notes

Version 1.07

- Receive app:
 - In Normal view Universe is not shown when protocol is DMX.
 - Store Scenes UI restructured:
 - Create new Table Menu format with heading for columns.
 - When Saving on existing scene, confirmation screen shows with warning that scene is already in use.
 - Long press on Delete button issues delete all scenes with confirmation screen.
- Send app:
 - Universe is not shown when protocol is DMX.
 - Store and Load Scenes UI restructured:
 - Create new Table Menu format with heading for columns.
 - When Saving on existing scene, confirmation screen shows with warning that scene is already in use.
 - Long press on Delete button issues delete all scenes with confirmation screen.
- Rdm app:
 - Enable set on FACTORY_DEFAULTS PID.
- Timings app:
 - Add Error color when signal is in ERROR state.
 - Show up exact number of received channels, up to 999, after that >999.
- Tracer app:
 - When universe invalid for protocol, protocol indication is also invalid.
 - Universe is not shown when protocol is DMX.
- Flicker Finder app:
 - When universe invalid for protocol, protocol indication is also invalid.
 - Universe is not shown when protocol is DMX.

- Playback app:
 - Allows to create and play up to 6 Sequences containing up to 99 steps with scene id, step time and fade time.
 - Selection of active protocol similar to receive app using the routing soft key.
 - Each Sequence can be modified with options:
 - Rename of Sequence.
 - Add, remove, edit or reorder steps containing Scene, Step Time in ms and Fade Time in ms. Step is red if scene that is used is deleted.
 - Delete whole Sequence - delete all steps and rename it to Empty.
 - Each Sequence if has steps inside can be played. It will issue play of scenes added to steps, taking into consideration:
 - Step time - Time that each step lasts.
 - Fade time - time where we fade current channel value into new channel provided by next scene.
 - Playback main screen indications:
 - White tile: Sequence exists and has steps inside. There is indication if it is Played/Paused or Stopped.
 - Gray tile: Sequence does not have steps inside. Cannot be played.
 - Red tile: Current step contains scene that is deleted - output hold previous value.
- USB File Transfer app:
 - Recreate initial file system if deleted.
 - Add busy bar when exiting application.

Version 1.06

Initial release.